




















































# SHARP社製 壁掛け金具対応表


















掲載がないテレビ型番については、対応確認をいたしますのでお問い合わせください


















サイズ (型)	テレビ型式	EEX-TVKA003	EEX-TVKA008	EEX-TVKA016	EEX-TVKA020WH	EEX-TVKA022	EEX-TVKA023	EEX-TVKA024	EEX-TVKA025	EEX-TVKA026	EEX-TVKA027	EEX-TVKA028	EEX-TVKA030	EEX-TVKA032	EEX-TVKA033	EEX-TVKA031BK	EEX-TVKA013/015	EEX-LA024/025
		32~65型	27~55型	32~65型	32~70型	42~80型	~43型	32~75型	37~70型	32~55型	55~80型	32~65型	42~100型	37~70型	~100型	49型まで	43型まで	15~43型
																		
85	8T-C85DX1	x	x	x	x	x	x	x	x	x	x	x	○	x	○	x	x	x
80	8T-C80AX1	x	x	x	x	○	x	x	x	x	x	○	x	○	x	○	x	x
	LC-80GL7	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-80XL10	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-80XL9	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-80XU30	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
77	PN-H801	x	x	x	x	○	x	x	x	x	○	x	○	x	○	x	x	x
	4T-C77EQ1	x	x	x	x	○	x	x	x	x	○	x	○	x	○	x	x	x
75	4T-C77GQ1	x	x	x	x	○	x	x	x	x	○	x	○	x	○	x	x	x
	4T-C75EP1	x	x	x	x	○	x	○	x	x	○	x	○	x	○	x	x	x
	4T-C75EL1	x	x	x	x	○	x	○	x	x	○	x	○	x	○	x	x	x
	4T-C75FN1	x	x	x	x	○	x	○	x	x	○	x	○	x	○	x	x	x
	4T-C75GN1	x	x	x	x	○	x	○	x	x	○	x	○	x	○	x	x	x
	4T-C75GP1	x	x	x	x	○	x	○	x	x	○	x	○	x	○	x	x	x
	8T-C75DX1	x	x	x	x	○	x	○	x	x	○	x	○	x	○	x	x	x
70	PN-HW751	x	x	x	x	○	x	○※2	x	x	○	x	○	x	○	x	x	x
	4T-C70AU1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C70BN1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C70CN1	x	x	x	○	○	x	○	○	x	○	x	○	○	○	x	x	x
	4T-C70DN1	x	x	x	○	○	x	○	○	x	○	x	○	○	○	x	x	x
	4T-C70EN1	x	x	x	○	○	x	○	○	x	○	x	○	○	○	x	x	x
	4T-C70EP1	x	x	x	○	○	x	○	○	x	○	x	○	○	○	x	x	x
	8T-C70AX1	x	x	x	○	○	x	○	x	x	○	x	○	○	○	x	x	x
	8T-C70BW1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	8T-C70CX1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	8T-C70DW1	x	x	x	○	○	x	○	○	x	○	x	○	○	○	x	x	x
	LC-70UD20	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-70US4	x	x	x	○	○	x	○	○	x	○	x	○	○	○	x	x	x
	LC-70X5	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-70X500	x	x	x	○	○	x	○	x	x	○	x	○	○	○	x	x	x
	LC-70XG35	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-70XL10	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
PN-E702	x	x	x	x	○	x	○	x	x	○	x	○	○	○	x	x	x	
PN-E703	x	x	x	x	○	x	○	x	x	○	x	○	○	○	x	x	x	
PN-L703B	x	x	x	x	x	x	○	x	x	x	x	x	x	x	x	x	x	
PN-R701	x	x	x	○	○	x	○	○	x	○	x	○	○	○	x	x	x	
PN-R703	x	x	x	○	○	x	○	○	x	○	x	○	○	○	x	x	x	
65	4T-C65CH1	○	x	○	○	○	x	○	○	x	○	○	○	○	○	x	x	x
	4T-C65CQ1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C65DL1	○	x	○	○	○	x	○	○	x	○	○	○	○	○	x	x	x
	4T-C65DN1	○	x	○	○	○	x	○	○	x	○	○	○	○	○	x	x	x
	4T-C65DP1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C65DQ1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C65DQ2	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
4T-C65DS1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	
	4T-C65EJ1	○	x	○	○	○	x	○	○	x	○	○	○	○	○	x	x	x



サイズ (型)	テレビ型式	EEX-TVKA003	EEX-TVKA008	EEX-TVKA016	EEX-TVKA020WH	EEX-TVKA022	EEX-TVKA023	EEX-TVKA024	EEX-TVKA025	EEX-TVKA026	EEX-TVKA027	EEX-TVKA028	EEX-TVKA030	EEX-TVKA032	EEX-TVKA033	EEX-TVKA031BK	EEX-TVKA013/015	EEX-LA024/025
		32~65型	27~55型	32~65型	32~70型	42~80型	~43型	32~75型	37~70型	32~55型	55~80型	32~65型	42~100型	37~70型	~100型	49型まで	43型まで	15~43型
																		
60	LC-60Z5	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-60Z9	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	PN-E601	x	x	x	○	○	x	○	x	x	○	○	○	○	○	x	x	x
	PN-E603	x	x	○	○	○	x	○	○	x	○	○	○	○	○	x	x	x
	PN-HM651	○	x	○	○	○	x	○	○	x	○	○	○	○	○	x	x	x
	PN-L601B	x	x	x	x	x	x	○	x	x	x	x	x	x	x	x	x	x
	PN-L602B	x	x	x	x	x	x	○	x	x	x	x	x	x	x	x	x	x
	PN-R603	○	x	○	○	○	x	○	○	x	○	○	○	○	○	x	x	x
PN-R606	○	x	○	○	○	x	○	○	x	○	○	○	○	○	x	x	x	
58	LC-58U30	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
55	4T-C55AJ1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C55BL1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C55CH1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C55CL1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C55CN1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C55CQ1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C55DN1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C55DP1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C55DQ1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C55DQ2	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C55DS1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C55EP1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C55EQ1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C55ES1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C55FN1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C55FN2	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C55FQ1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C55FS1	○	○	○	○	○	x	○	○	○	○	○	○	○	○	x	x	x
	4T-C55GN1	○	x	○	x	○	x	○	○	○	○	○	○	○	○	x	x	x
	4T-C55GN2	○	x	○	x	○	x	○	○	○	○	○	○	○	○	x	x	x
	4T-C55GP1	○	x	○	○	○	x	○	○	○	○	○	○	○	○	x	x	x
	4T-C55GQ1	○	x	○	○	○	x	○	○	○	○	○	○	○	○	x	x	x
	4T-C55GQ3	○	x	○	○	○	x	○	○	○	○	○	○	○	○	x	x	x
	4T-C55GS1	○	x	○	○	○	x	○	○	○	○	○	○	○	○	x	x	x
	LC-55U30	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-55U40	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-55U45	○	○	○	○	○	x	○	○	○	○	○	○	○	○	x	x	x
	LC-55UH5	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-55US40	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-55US45	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-55US5	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-55W30	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
LC-55W35	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	
LC-55XD45	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	
PN-HW551	○	○	○	○	○	x	○	○	○	○	○	○	○	○	x	x	x	
PN-U553	○	○	○	○	○	x	○	○	○	○	○	○	○	○	x	x	x	
PN-Y555	○	○	○	○	○	x	○	○	○	○	○	○	○	○	x	x	x	
PN-Y556	○	x	○	○	○	x	○	○	○	○	○	○	○	○	x	x	x	

サイズ (型)	テレビ型式	EEX-TVKA003	EEX-TVKA008	EEX-TVKA016	EEX-TVKA020WH	EEX-TVKA022	EEX-TVKA023	EEX-TVKA024	EEX-TVKA025	EEX-TVKA026	EEX-TVKA027	EEX-TVKA028	EEX-TVKA030	EEX-TVKA032	EEX-TVKA033	EEX-TVKA031BK	EEX-TVKA013/015	EEX-LA024/025
		32~65型	27~55型	32~65型	32~70型	42~80型	~43型	32~75型	37~70型	32~55型	55~80型	32~65型	42~100型	37~70型	~100型	49型まで	43型まで	15~43型
																		
52	LC-52DZ3	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-52ES50	o	o	o	o	o	x	o	o	o	o	o	o	o	o	x	x	x
	LC-52EX5	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-52G9	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-52GX1W	x	x	x	o	o	x	o	o	o	o	o	o	o	o	x	x	x
	LC-52L5	x	o	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-52LX3	x	x	x	x	x	x	x	o	o	o	x	x	x	x	x	x	x
	LC-52SE1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-52UD20	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-52US20	o	o	o	o	o	x	o	o	o	o	o	o	o	o	x	x	x
	LC-52US30	o	o	o	o	o	x	o	o	o	o	o	o	o	o	x	x	x
	LC-52W10	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-52XL20	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-52XL9	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
LC-52Z5	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	
PN-E521	o	o	o	o	o	x	o	o	o	o	o	o	o	o	x	x	x	
50	4T-C50AH1	o	x	o	x	x	x	x	o	o	x	x	x	x	x	x	x	x
	4T-C50AH2	o	o	o	o	o	x	o	o	o	x	x	o	o	o	x	x	x
	4T-C50AJ1	o	x	o	x	x	x	x	o	o	x	x	x	x	x	x	x	x
	4T-C50AM1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C50AN1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C50BH1	o	x	o	o	o	x	o	o	o	x	o	o	o	o	x	x	x
	4T-C50BL1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C50BN1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C50CH1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C50CL1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C50CN1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C50DL1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C50DN2	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C50EJ1	o	o	o	x	o	x	o	o	o	x	o	o	o	o	x	x	x
	4T-C50EL1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C50FL1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C50FN2	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	4T-C50GN2	o	x	o	x	o	x	o	o	o	x	o	o	o	o	x	x	x
	4T-C50GP2	o	x	o	x	o	x	o	o	o	x	o	o	o	o	x	x	x
	LC-50BW30	o	o	o	x	x	x	o	o	o	x	x	x	x	x	x	x	x
	LC-50U20	o	o	o	x	x	x	o	o	o	x	x	x	x	x	x	x	x
	LC-50U30	o	o	o	x	x	x	o	o	o	x	x	x	x	x	x	x	x
	LC-50U40	o	x	o	x	x	x	o	o	o	x	x	x	x	x	x	x	x
	LC-50U45	o	x	o	x	x	x	o	o	o	x	x	x	x	x	x	x	x
	LC-50US40	o	x	o	x	x	x	o	o	o	x	x	x	x	x	x	x	x
	LC-50US45	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-50US5	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-50W20	o	o	o	x	x	x	o	o	o	x	x	x	x	x	x	x	x
LC-50W30	o	o	o	x	x	x	o	o	o	x	x	x	x	x	x	x	x	
LC-50W35	o	o	o	x	x	x	o	o	o	x	x	x	x	x	x	x	x	
PN-HS501	o	o	o	o	o	x	o	o	o	x	o	o	o	o	x	x	x	
PN-HW501	o	o	o	o	o	x	o	o	o	x	o	o	o	o	x	x	x	
PN-HY501	o	o	o	o	o	x	o	o	o	x	o	o	o	o	x	x	x	

サイズ (型)	テレビ型式	EEX-TVKA003	EEX-TVKA008	EEX-TVKA016	EEX-TVKA020WH	EEX-TVKA022	EEX-TVKA023	EEX-TVKA024	EEX-TVKA025	EEX-TVKA026	EEX-TVKA027	EEX-TVKA028	EEX-TVKA030	EEX-TVKA032	EEX-TVKA033	EEX-TVKA031BK	EEX-TVKA013/015	EEX-LA024/025
		32~65型	27~55型	32~65型	32~70型	42~80型	~43型	32~75型	37~70型	32~55型	55~80型	32~65型	42~100型	37~70型	~100型	49型まで	43型まで	15~43型
																		
49	PN-R496	○	○	○	○	○	×	○	○	○	×	○	○	○	○	×	×	×
	PN-Y496	○	○	○	○	○	×	○	○	○	×	○	○	○	○	×	×	×
48	4T-C48GQ2	○	×	○	×	○	×	×	○	○	×	×	○	○	○	×	×	×
	4T-C48GQ3	○	×	○	×	○	×	×	○	○	×	×	○	○	○	×	×	×
47	PN-E471R	○	○	○	○	○	×	○	○	○	×	○	○	○	○	○※3-2	×	×
46	LC-46AE7	○	○	○	○	○	×	×	○	○	×	×	○	×	○	×	×	×
	LC-46DX1	×	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
	LC-46DX2	×	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
	LC-46DX3	○	○	○	○	○	×	×	○	○	×	×	○	×	○	×	×	×
	LC-46DZ3	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
	LC-46ES50	○	○	○	○	○	×	○	○	○	×	○	○	○	○	×	×	×
	LC-46F5	○	×	○	×	○	×	×	○	○	×	×	○	×	○	×	×	×
	LC-46G9	○	○	○	○	○	×	×	○	○	×	×	○	×	○	×	×	×
	LC-46LX1	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
	LC-46RX1W	○	○	○	○	○	×	×	○	○	×	×	○	×	○	×	×	×
	LC-46V5	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
	LC-46W10	○	○	○	×	×	×	×	○	○	×	×	×	×	×	×	×	×
	LC-46W9	○	○	○	×	×	×	×	○	○	×	×	×	×	×	×	×	×
	LC-46XL10	○	○	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
LC-46XL20	○	○	○	○	○	×	×	○	○	×	×	○	×	○	×	×	×	
45	4T-C45AJ1	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
	4T-C45AL1	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
	4T-C45BL1	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
	4T-C45BN1	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
	LC-45US40	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
	LC-45US45	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
LC-45W5	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	
43	4T-C43AM1	○	○	○	○	○	×	○	○	○	×	×	○	×	○	×	×	×
	4T-C43CL1	○	○	○	○	○	○	×	○	○	×	×	○	×	○	×	×	○
	4T-C43CN1	○	○	○	○	○	○	×	○	○	×	×	○	×	○	×	×	○
	4T-C43DL1	○	○	○	○	○	×	○	○	○	×	×	○	×	○	×	×	○
	4T-C43DN2	○	○	○	○	○	○	×	○	○	×	×	○	×	○	×	×	○
	4T-C43EL1	○	○	○	○	○	○	○	○	○	×	×	○	×	○	×	○	○
	4T-C43FN2	○	○	○	○	○	○	○	○	○	×	×	○	×	○	×	○	○
	4T-C43GP2	○	○	○	○	○	○	○	○	○	×	×	○	×	○	○	○	○
	PN-HS431	○	○	○	○	○	○	○	○	○	×	×	○	×	○	○	○	○
	PN-HW431	○	○	○	○	○	○	○	○	○	×	○	○	○	○	○	○	○
PN-W435A	○	○	○	○	○	○	○	○	○	×	○	○	○	○	○	○	○	
PN-Y436	○	○	○	○	○	○	○	○	○	×	○	○	○	○	×	×	×	
42	2T-C42BE1	×	○※1	×	×	×	○※1	×	×	×	×	×	×	×	×	○	○	○
	4T-C42DJ1	○	○	○	×	×	○	×	○	○	×	×	×	×	×	×	×	×
	4T-C42EJ1	○	○	○	×	×	○	×	○	○	×	×	×	×	×	×	×	×
	4T-C42EQ2	○	○	○	○	○	×	×	○	○	×	×	○	×	○	×	×	×
	4T-C42FL1	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
	4T-C42GQ2	○	○	○	×	○	○	○	○	○	×	○	○	○	○	×	×	×
	LC-42DS5	○	○	○	○	○	○	○	○	○	×	○	○	○	○	×	×	×
	LC-42DS6	○	○	○	○	○	○	○	○	○	×	○	○	○	○	×	×	×
LC-42EX5	○	○	○	○	○	○	○	○	○	×	○	○	○	○	×	×	×	
LC-42GX5	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	
42	PN-R426	○	○	○	○	○	○	○	○	○	×	○	○	○	○	○	○	×
	PN-Y425	○	○	○	○	○	○	○	○	○	×	○	○	○	○	×	×	×

サイズ (型)	テレビ型式	EEX-TVKA003	EEX-TVKA008	EEX-TVKA016	EEX-TVKA020WH	EEX-TVKA022	EEX-TVKA023	EEX-TVKA024	EEX-TVKA025	EEX-TVKA026	EEX-TVKA027	EEX-TVKA028	EEX-TVKA030	EEX-TVKA032	EEX-TVKA033	EEX-TVKA031BK	EEX-TVKA013/015	EEX-LA024/025
		32~65型	27~55型	32~65型	32~70型	42~80型	~43型	32~75型	37~70型	32~55型	55~80型	32~65型	42~100型	37~70型	~100型	49型まで	43型まで	15~43型
																		
40	2T-B40AB1	x	x	x	x	x	○※1	x	x	x	x	x	x	x	x	○	○	○
	2T-C40AE1	x	x	x	x	x	○※1	x	x	x	x	x	x	x	x	○	○	○
	2T-C40BE1	x	x	x	x	x	○※1	x	x	x	x	x	x	x	x	○	○	○
	4T-C40AJ1	○	○	○	○	x	○	x	○	○	x	x	x	x	x	x	x	○
	4T-C40BH1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	○
	4T-C40BJ1	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	○	○
	4T-C40CL1	○	○	x	x	x	○	x	x	x	x	x	x	x	x	x	x	○
40	LB-T401	○	○	x	x	x	○	x	x	x	x	x	x	x	x	x	○	○
	LC-40AE6	○	○	○	○	x	○	○	○	x	○	x	○	○	○	x	x	x
	LC-40AE7	○	○	○	○	x	○	x	○	○	x	x	x	○	x	x	x	x
	LC-40AJ1	○	○	○	○	x	○	○	○	○	x	x	x	○	x	x	x	○
	LC-40BH11	x	○※1	x	x	x	○※1	x	x	x	x	x	x	x	x	x	○	○
	LC-40BH30	x	○※1	x	x	x	○※1	x	x	x	x	x	x	x	x	x	○	○
	LC-40DR9	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-40DS6	○	○	○	○	x	○	○	○	x	○	x	○	○	○	x	x	x
	LC-40DX2	○	x	x	○	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-40E40	○	x	○	x	x	x	x	x	x	x	x	x	x	○	x	x	x
	LC-40E9	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-40G7	○	x	○	x	x	x	x	○	○	x	x	x	x	○	x	x	x
	LC-40G9	○	x	○	x	x	x	x	○	○	x	x	x	x	○	x	x	x
	LC-40H11	x	x	x	x	x	○※1	x	x	x	x	x	x	x	x	○	○	○
	LC-40H20	x	x	x	x	x	○※1	x	x	x	x	x	x	x	x	○	○	○
	LC-40H30	x	x	x	x	x	○※1	x	x	x	x	x	x	x	x	○	○	○
	LC-40H40	x	x	x	x	x	○※1	x	x	x	x	x	x	x	x	○	○	○
	LC-40H9	○	x	x	x	x	x	x	○	○	x	x	x	x	x	x	x	x
	LC-40HW10	○	x	x	○	x	x	x	○	○	x	x	x	x	x	x	x	x
	LC-40HW20	○	○	x	○	x	○	x	○	○	x	x	x	x	x	x	x	x
	LC-40HW35	○	○	x	○	x	○	x	○	○	x	x	x	x	x	x	x	x
	LC-40J10	○	x	x	x	x	x	x	○	○	x	x	x	x	x	x	x	x
	LC-40LV3	○	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-40LX3	○	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-40R30	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-40S5	x	x	x	x	x	○※1	x	x	x	x	x	x	x	x	○	○	
	LC-40SE1	○	○	○	○	x	○	x	○	○	x	x	x	x	○	x	x	x
	LC-40U20	○	○	x	○	x	○	x	○	○	x	x	x	x	x	x	x	○
	LC-40U30	○	○	x	○	x	○	x	○	○	x	x	x	x	x	x	x	○
	LC-40U40	○	○	x	○	x	○	x	○	○	x	x	x	x	x	x	x	○
	LC-40U45	○	○	x	○	x	○	x	○	○	x	x	x	x	x	x	x	○
	LC-40V5	○	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-40V7	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	LC-40W20	○	x	x	○	x	x	x	○	○	x	x	x	x	x	x	x	x
LC-40W35	○	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	
LC-40W5	○	○	○	○	x	○	○	○	○	x	x	x	x	○	x	○	○	
LC-40Z5	○	x	○	x	x	x	x	○	○	x	x	x	x	○	x	x	x	
PN-B401	○	○	○	○	x	○	○	○	○	x	○	x	○	○	○※3-3	x	x	
PN-M401	○	○	○	○	x	○	○	○	○	x	○	x	○	○	○※3-3	x	x	
37	LC-37DS5	○	○	○	x	x	○	○	○	○	x	○	x	x	○	x	x	x
	LC-37ES50	○	○	○	x	x	○	○	○	x	○	x	x	x	○	x	x	x

サイズ (型)	テレビ型式	EEX-TVKA003	EEX-TVKA008	EEX-TVKA016	EEX-TVKA020WH	EEX-TVKA022	EEX-TVKA023	EEX-TVKA024	EEX-TVKA025	EEX-TVKA026	EEX-TVKA027	EEX-TVKA028	EEX-TVKA030	EEX-TVKA032	EEX-TVKA033	EEX-TVKA031BK	EEX-TVKA013/015	EEX-LA024/025
		32~65型	27~55型	32~65型	32~70型	42~80型	~43型	32~75型	37~70型	32~55型	55~80型	32~65型	42~100型	37~70型	~100型	49型まで	43型まで	15~43型
							縦設置専用											
37	LC-37EX5	○	○	○	×	×	○	○	○	○	×	○	×	×	○	×	×	×
	LC-37GS10	○	○	○	○	×	○	○	○	○	×	○	×	×	○	○※3-2	×	×
	LC-37GX3W	○	○	○	×	×	○	○	○	○	×	○	×	×	○	×	×	×
	LC-37GX5	○	○	○	×	×	○	○	○	○	×	○	×	×	○	×	×	×
32	2T-C32AE1	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	○	○	○
	2T-C32DE	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	○	○	○
	2T-C32EF1	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	○※3-2	○	○
	LC-32BD1	○	○	○	○	×	○	○	×	○	×	○	×	×	○	×	×	○
	LC-32BH11	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	○	○	○
	LC-32BH30	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	○	○	○
	LC-32D10	○	○	○	○	×	○	○	×	○	×	○	×	×	○	×	×	○
32	LC-32D30	○	○	○	○	×	○	○	×	○	×	○	×	×	○	×	×	○
	LC-32DE5	○	○	○	○	×	○	○	×	○	×	○	×	×	○	×	○	○
	LC-32DR3	○	○	○	○	×	○	×	×	○	×	×	×	×	○	×	○	○
	LC-32DX3	○	○	○	○	×	○	×	×	○	×	×	×	×	○	×	×	○
	LC-32E40	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	×	○	○
	LC-32E7	○	○	○	○	×	○	○	×	○	×	○	×	×	○	×	×	○
	LC-32E8	○	○	○	○	×	○	○	×	○	×	○	×	×	○	○※3-2	○	○
	LC-32ES	○	○	○	○	×	○	×	×	○	×	×	×	×	○	×	×	○
	LC-32F3	○	○	○	○	×	○	×	×	○	×	×	×	×	○	×	○	○
	LC-32F5	○	○	○	○	×	○	×	×	○	×	×	×	×	○	×	○	○
	LC-32GH1	○	○	○	○	×	○	○	×	○	×	○	×	×	○	×	×	×
	LC-32H11	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	○	○	○
	LC-32H20	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	○	○	○
	LC-32H30	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	○	○	○
	LC-32H40	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	○	○	○
	LC-32H9	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	○	○	○
	LC-32J10	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	○	○	○
	LC-32J9	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	○	○	○
	LC-32R30	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×	×
	LC-32R5	○	○	○	○	×	○	×	○	○	×	×	×	×	○	○	○	○
	LC-32S5	×	○※1	×	×	×	○※1	×	×	×	×	×	×	×	×	○	○	○
	LC-32SC1	○	○	○	○	×	○	×	○	×	×	×	×	×	○	○※3-2	○	○
	LC-32V5	○	○	×	×	×	○	×	×	×	×	×	×	×	×	○※3-2	○	○
	LC-32W25	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	○	○	○
	LC-32W5	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	○	○	○
	PN-Y326	○	○	○	○	×	○	○	×	○	×	○	×	×	○	○※3-2	○	○
PN-Y326B	○	○	○	○	×	○	○	×	○	×	○	×	×	○	○※3-2	○	○	
24	2T-C24AD	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	○	○	○
	LC-24P5	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	○	○	○
22	2T-C22AD	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	○	○	○
	LC-22K45	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	○	○	○
19	2T-C19AD	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	○	○	○
	LC-19P5	×	×	×	×	×	○※1	×	×	×	×	×	×	×	×	○	○	○

※1 ネジが付属しておりません  
取り付けネジが別途必要です。(M4など)  
※2 縦向き設置のみ可能

※3-2 別途変換金具 EEX-VESATF02 が必要で  
テレビを取付のネジは別途必要な場合があります。  
※3-3 別途変換金具 EEX-VESATF03 が必要で  
テレビを取付のネジは別途必要な場合があります。

※4 ブラケットがテレビ下部よりはみ出す可能性があります。