










サイズ (型)	テレビ型式	EEX-TVKA003	EEX-TVKA008	EEX-TVKA011	EEX-TVKA016	EEX-TVKA020WH	EEX-TVKA022	EEX-TVKA024	EEX-TVKA013/014/015	EEX-LA024/025
		32~65型	27~55型	32~70型	32~65型	32~70型	42~80型	32~75型	43型まで	15~43型
										
49	PN-R496	○	○	○	○	○	○	○	×	×
	PN-Y496	○	○	○	○	○	○	○	×	×
47	PN-E471R	○	○	○	○	○	○	○	×	×
46	LC-46AE7	○	○	○	○	○	○	×	×	×
	LC-46DX1	×	○	×	×	×	×	×	×	×
	LC-46DX2	×	○	×	×	×	×	×	×	×
	LC-46DX3	○	○	○	○	○	○	×	×	×
	LC-46DZ3	×	×	×	×	×	×	×	×	×
	LC-46ES50	○	○	○	○	○	○	○	×	×
	LC-46F5	○	×	○	○	○	○	×	×	×
	LC-46G9	○	○	○	○	○	○	×	×	×
	LC-46LX1	×	×	×	×	×	×	×	×	×
	LC-46RX1W	○	○	○	○	○	○	×	×	×
	LC-46V5	×	×	×	×	×	×	×	×	×
	LC-46W10	○	○	○	○	○	○	×	×	×
	LC-46W9	○	○	○	○	○	○	×	×	×
	LC-46XL10	○	○	×	×	×	×	×	×	×
LC-46XL20	○	○	○	○	○	○	×	×	×	
45	4T-C45AJ1	×	×	×	×	×	×	×	×	×
	4T-C45AL1	×	×	×	×	×	×	×	×	×
	4T-C45BL1	×	×	×	×	×	×	×	×	×
	4T-C45BN1	×	×	×	×	×	×	×	×	×
	LC-45US40	×	×	×	×	×	×	×	×	×
	LC-45US45	×	×	×	×	×	×	×	×	×
43	4T-C43AM1	○	○	○	○	○	○	×	×	×
	4T-C43CL1	○	○	○	○	○	○	×	×	○
	4T-C43CN1	○	○	○	○	○	○	×	×	○
	4T-C43DL1	○	○	○	○	○	○	×	×	○
	4T-C43DN2	○	○	○	○	○	○	×	×	○
	PN-HW431	○	○	○	○	○	○	○	○	○
	PN-W435A	○	○	○	○	○	○	○	○	○
	PN-Y436	○	○	○	○	○	○	○	×	×
42	2T-C42BE1	×	○※1	×	○※1	×	×	×	○	○
	4T-C42DJ1	○	○	○	○	○	○	×	×	×
	LC-42DS5	○	○	○	○	○	○	○	×	×
	LC-42DS6	○	○	○	○	○	○	○	×	×
	LC-42EX5	○	○	○	○	○	○	○	×	×
	LC-42GX5	×	×	×	×	×	×	×	×	×
	PN-R426	○	○	○	○	○	○	○	×	×
40	PN-Y425	○	○	○	○	○	○	○	×	×
	2T-B40AB1	×	○※1	×	○※1	×	×	×	○	○
	2T-C40AE1	×	○※1	×	○※1	×	×	×	○	○
	2T-C42BE1	×	○※1	×	○※1	×	×	×	○	○
	4T-C40AJ1	○	○	○	○	○	○	×	×	○
	4T-C40BH1	×	×	×	×	×	×	×	○	○
	4T-C40BJ1	×	×	×	×	×	×	×	○	○
	4T-C40CL1	○	○	×	×	×	×	×	×	○
	LB-T401	○	○	×	×	×	×	×	○	○
	LC-40AE6	○	○	○	○	○	○	○	×	×
	LC-40AE7	○	○	○	○	○	○	×	×	×
	LC-40AJ1	○	○	○	○	○	○	○	×	○
	LC-40BH11	×	○※1	×	○※1	×	×	×	○	○
	LC-40BH30	×	○※1	×	○※1	×	×	×	○	○
	LC-40DR9	×	×	×	×	×	×	×	×	×
	LC-40DS6	○	○	○	○	○	○	○	×	×
	LC-40DX2	○	×	×	×	○	○	×	×	×
	LC-40E40	○	×	×	○	×	×	×	×	×
	LC-40E9	×	×	×	×	×	×	×	×	×
	LC-40G7	○	×	○	○	○	○	×	×	×
	LC-40G9	○	×	○	○	○	○	×	×	×
	LC-40H11	×	○※1	×	○※1	×	×	×	○	○
	LC-40H20	×	○※1	×	○※1	×	×	×	○	○
LC-40H30	×	○※1	×	○※1	×	×	×	○	○	
LC-40H40	×	○※1	×	○※1	×	×	×	○	○	
LC-40H9	○	×	○	×	○	○	×	×	×	
LC-40HW10	○	×	○	×	○	○	×	×	×	
LC-40HW20	○	○	○	×	○	○	×	×	○	
LC-40HW35	○	○	○	×	○	○	×	×	○	

サイズ (型)	テレビ型式	EEX-TVKA003	EEX-TVKA008	EEX-TVKA011	EEX-TVKA016	EEX-TVKA020WH	EEX-TVKA022	EEX-TVKA024	EEX-TVKA013/014/015	EEX-LA024/025
		32~65型	27~55型	32~70型	32~65型	32~70型	42~80型	32~75型	43型まで	15~43型
40	LC-40J10	○	×	○	×	○	○	×	×	×
	LC-40LX3	○	×	×	×	○	○	×	×	×
	LC-40LV3	○	×	×	×	○	○	×	×	×
	LC-40R30	×	×	×	×	×	×	×	×	×
	LC-40S5	×	○※1	×	○※1	×	×	×	○	○
	LC-40SE1	○	○	○	○	○	○	×	×	×
	LC-40U20	○	○	○	×	○	○	×	×	○
	LC-40U30	○	○	○	×	○	○	×	×	○
	LC-40U40	○	○	○	×	○	○	×	×	○
	LC-40U45	○	○	○	×	○	○	×	×	○
	LC-40V5	○	×	×	×	○	○	×	×	×
	LC-40V7	×	×	×	×	○	○	×	×	×
	LC-40W20	○	×	○	×	○	○	×	×	○
	LC-40W35	○	×	×	×	×	×	×	×	○
	LC-40W5	○	○	○	○	○	○	○	○	○
	LC-40Z5	○	×	○	○	○	○	○	×	×
PN-B401	○	○	○	○	○	○	○	×	×	
PN-M401	○	○	○	○	○	○	○	×	×	
37	LC-37DS5	○	○	○	○	○	○	○	×	×
	LC-37GS10	○	○	○	○	○	○	○	×	×
	LC-37ES50	○	○	○	○	○	○	○	×	×
	LC-37EX5	○	○	○	○	○	○	○	×	×
	LC-37GX3W	○	○	○	○	○	○	○	×	×
	LC-37GX5	○	○	○	○	○	○	○	×	×
32	2T-C32AE1	×	○※1	×	○※1	×	×	×	○	○
	2T-C32DE	×	○※1	×	○※1	×	×	×	○	○
	LC-32BD1	○	○	○	○	○	○	○	×	○
	LC-32BH11	×	○※1	×	×	×	×	×	○	○
	LC-32BH30	×	○※1	×	×	×	×	×	○	○
	LC-32D10	○	○	○	○	○	○	○	×	○
	LC-32D30	○	○	○	○	○	○	○	×	○
	LC-32DE5	○	○	○	○	○	○	○	○	○
	LC-32DX3	○	○	○	○	○	○	×	×	○
	LC-32DR3	○	○	○	○	○	○	×	○	○
	LC-32E40	×	○※1	×	○※1	×	×	×	○	○
	LC-32E7	○	○	○	○	○	○	○	×	○
	LC-32E8	○	○	○	○	○	○	○	○	○
	LC-32ES	○	○	○	○	○	○	×	×	○
	LC-32F3	○	○	○	○	○	○	×	○	○
	LC-32F5	○	○	○	○	○	○	×	○	○
	LC-32GH1	○	○	○	○	○	○	○	×	×
	LC-32H11	×	○※1	×	○※1	×	×	×	○	○
	LC-32H20	×	○※1	×	○※1	×	×	×	○	○
	LC-32H30	×	○※1	×	○※1	×	×	×	○	○
	LC-32H40	×	○※1	×	○※1	×	×	×	○	○
	LC-32H9	×	○※1	×	○※1	×	×	×	○	○
	LC-32J10	×	○※1	×	○※1	×	×	×	○	○
	LC-32J9	×	○※1	×	○※1	×	×	×	○	○
	LC-32R30	×	×	×	×	×	×	×	×	×
	LC-32R5	○	×	○	○	○	○	×	×	×
LC-32S5	×	○※1	×	○※1	×	×	×	○	○	
LC-32SC1	○	○	○	○	○	○	×	○	○	
LC-32V5	○	○	×	○※1	×	×	×	○	○	
LC-32W25	×	○※1	×	○※1	×	×	×	○	○	
LC-32W5	×	○※1	×	○※1	×	×	×	○	○	
PN-Y326	○	○	○	○	○	○	○	○	○	
24	2T-C24AD	×	○※1	×	×	×	×	×	○	○
	LC-24P5	×	○※1	×	×	×	×	×	○	○
22	2T-C22AD	×	×	×	×	×	×	×	○	○
	LC-22K45	×	×	×	×	×	×	×	○	○
19	2T-C19AD	×	×	×	×	×	×	×	○	○
	LC-19P5	×	×	×	×	×	×	×	○	○

※1 ネジが付属していません

取り付けネジが別途必要です。(M4など)

※2 縦向き設置のみ可能